




MANUFACTURAS WRAKYNSON

REF.	APLICACION	SITUACION	FECHA APLICAC.	LARGO TOTAL	
------	------------	-----------	----------------	-------------	--

TALBOT


1307, 1308, 1309

70035 ALL TYPES T ↔ 75 -> 82 330




1510

70034 ALL TYPES D ↔ 75 -> 82 365




HORIZON

70034 ALL TYPES D ↔ 78 -> 86 365




70035 ALL TYPES T ↔ 78 -> 87 330




RANCHO

70034 ALL TYPES D ↔ 77 -> 84 365




SAMBA


70016 1.0, 1.1, 1.4 D ↔ 81 -> 86 370



70076 1.0, 1.1, 1.4 T → 81 -> 86 280




70081 ALL TYPES T ← 81 -> 86 305




SIMCA 1200, 1100

70034 ALL TYPES D ↔ 75 -> 80 365




SIMCA 900, 1000

70012 ALL TYPES T ⊕ 68 -> 80 298



SOLARA

70034 ALL TYPES D ↔ 79 -> 87 365



↑ SUPERIOR, ↓ INFERIOR, ⊕ INTERMEDIO, ▣ INTERIOR, ◼ CENTRO



REF.	APLICACION	SITUACION	FECHA APLICAC.	LARGO TOTAL	
------	------------	-----------	----------------	-------------	--

TALBOT

SOLARA

70035	ALL TYPES	T ↔	79 -> 86	330	
--------------	-----------	-----	----------	-----	--

TAGORA

70034	2.2, 2.3 TD	D ↔	80 -> 87	365	
--------------	-------------	-----	----------	-----	--

70035	2.2, 2.3 TD	T ↔	80 -> 87	330	
--------------	-------------	-----	----------	-----	--

↑ SUPERIOR, ↓ INFERIOR, Ø INTERMEDIO, □ INTERIOR, ■ CENTRO